



## The Iris



### **AN EASTLAND COMMUNITY**

Drawing not to scale. All room dimensions are approximate, shown to maximum dimensions of each room and are subject to field variation. Dimensions should not be used to calculate room square footage. Some windows, exterior features and floor plan may vary with elevations. Please contact sales manager at (781) 417-9592 for details.





# The Iris



AREA
1,135 SF

## AN EASTLAND COMMUNITY

Drawing not to scale. All room dimensions are approximate, shown to maximum dimensions of each room and are subject to field variation. Dimensions should not be used to calculate room square footage. Some windows, exterior features and floor plan may vary with elevations. Please contact sales manager at (781) 417-9592 for details.





## The Iris



AREA
1,402 SF


### AN EASTLAND COMMUNITY

Drawing not to scale. All room dimensions are approximate, shown to maximum dimensions of each room and are subject to field variation. Dimensions should not be used to calculate room square footage. Some windows, exterior features and floor plan may vary with elevations. Please contact sales manager at (781) 417-9592 for details.





# The Iris



AREA
426 SF FINISHED BASEMENT
486 W/BATHROOM

## AN EASTLAND COMMUNITY

Drawing not to scale. All room dimensions are approximate, shown to maximum dimensions of each room and are subject to field variation. Dimensions should not be used to calculate room square footage. Some windows, exterior features and floor plan may vary with elevations. Please contact sales manager at (781) 417-9592 for details.

